





Button overview



Resetting the system

To fully reset this unit press the recessed **RESET** button with an insulated blunt probe.



Setting the 24-hour clock

NOTE: The 'CLOCK' button must be held throughout the entire procedure.


1. Use the **h+** button to set the present hour.
2. Use the **M+** button to set the present minute.
3. Using the **DAY** button, set the present day.
4. Release the **CLOCK** button to confirm.

Switching times

NOTE: You can set as many as six switching-on commands and an equal number of switching-off commands.

1. Press the **'TIMER'** enter the setting display.
2. Set the required switching-on time using **'h+' and 'M+'**
3. Using the **'DAY'** button, set the day(s) on which the command is required to be executed.
4. Press **'TIMER'** to set the switching-off time.
5. Set the required switching-off time using **'h+' and 'M+'**.
6. Using the **'DAY'** button, set the day(s) on which the command is required to be executed.
7. Press **'TIMER'** to begin setting a second program, when **'2 TIMER'** appears on the display you can begin setting a new program (repeat steps 2-6).

When you have finished setting the required times, press the **'CLOCK'** button to confirm and revert the present time.



Day selection buttons

Every day of the week
If you do not enter the day when setting a switching command, the switching will be carried out at the set time on every day of the week.

Only one day of the week
If you enter a particular day while setting a switching command (using the **'DAY'** button) the command will be carried out the set time only on that specific day of the week.

On a weekly combination (or 'block'programming)
When pressing the **'DAY'** button several times, you will notice that four combinations of days are available.

- MO TU WETH FRI = Monday to Friday
- SA SU = Saturday and Sunday
- MO TU WETH FR SA = Monday to Saturday
- MO TU WETH FR SA SU = Monday to

NOTE: If you enter these combinations of days instead of one individual day, the on/off command will be carried out at the set time on each of the days of the week.

This programmed will repeat itself weekly until the programme is changed, or the timer is disconnected.

Checking, changing or deleting commands

Checking
By pressing the **'TIMER'** a number of times you can make the switching-on and switching-off commands visible in the display: **first the set commands are presented and then the free spaces**


Changing
You can change a switching command by making it appear on the display and pressing **'DAY', 'h+' and 'M+'** buttons accordingly.

Deleting
Delete a timer command period (an **'on' and 'off' time**) by pressing the **'TIMER'** button until the required program number on-time is displayed in the window and pressing **'h+' until '- -'** is displayed immediately after 23. Repeat this with the **'M+' until '- -'** appears after 59.

Repeat this sequence for the 'off' mode.
The deleted command then becomes available for reprogramming.

Press the 'TIMER' button after changing or deleting a command to confirm/save your changes.

Switching back to present time
After setting the switching commands you can return to the present time by pressing the **'CLOCK'** button.



Override switch

When in the **'off'** mode, pressing the **'HAND'** button will switch on the power to the load connected to the timer. If the button is pressed again the power will switch off. If the button is not pressed again, power will remain on until the completion of the next on/off command when power will switch off.

If not pressed again the power will remain off until the following 'on' command has been reached

Note: When setting up programmes for the first time and the 1st 'ON' time has past - please press 'Override' button to initialise.



